



AGEPOFB

Disposable Bullet Shape Earplug

Features

- Foam polyurethane earplug features bullet-shape, which is designed for people with normal ear canal
- Soft, flexible and features a slow deformation, which can change the earplug shape according to the size of ear canal, ensuring a better sealing, maximum noise reduction and optimal hearing protection.
- 100% PVC-Free, slow rebound, various rebound time are welcomed
- Made of extra-soft, lightweight foam that seals the ear canal without pressure
- Bullet shape for a snug fit while gently conforming to the ear canal
- Easy to put on, are made from soft non-allergenic material
- Meet CE, ANSI and AS/NZS 1270 standards

Applications

AGEPOFB earplugs are able to prevent noise disturbance and provide hearing protection. Suitable for noisy environment covering home, dormitory, self-study room, travels, vehicles, airplanes, factories, construction site, bustling areas.

Recommended for the following activities:

Sleeping, Studying, Working, Watching Fireworks, Using Power Tools, Hunting, Racing, Traveling, Festivals, Industrial Sites, Construction Sites, Shooting Range, Yard Work Using Gas Powered Equipment, Sport Events, Public Places

Technical Specifications

Type: Polyurethane Earplug

Material: Polyurethane

SNR: 34dB

NRR: 32dB

AS/NZS SLC (80) 26.1dB CLASS5

Color: Orange

Packaging: 1 pair/polybag, 200 pairs/inner box, 4000 pairs/ctn

Country of origin: Made In China

Usage Instructions

- With clean fingers, roll the ear plug between your fingers using your thumb and index fingers. Roll the ear plug into a thin, snake-like shape. This will make it smaller and easier to insert.
- Pull your ear up and back by grabbing the top of your ear with the hand not holding the ear plug. Stretch it slightly up and backwards with a gentle tug. This will pull your ear open a bit, allowing you to more easily insert your earplug. Use a mirror if you're having trouble.
- Carefully insert the ear plug in the ear canal with a steady hand. Hold the ear plug inside your ear for 10-20 seconds while the foam expands to fill the ear canal.
- Repeat steps for the other AGEPOFB earplug