TECHNIWELDUSA



AGN95FF

NIOSH Disposable N95 Flat Fold Style Respirator

This NIOSH N95 Respirator provides 95% filter efficiency against solid and liquid particulates in the air. This includes irritants such as dust and other airborne allergens. These foldable, lightweight, and disposable N95 Respirators feature a latex-free filter for lower breathing resistance and comfort even in humid environments.

Features

- NIOSH N95 Protection for home & work
- 95% filter efficiency against solid and liquid particulates, excluding oils
- Humidity-resistant filter
- Adjustable nose bridge for better seal
- · Versatile elastic straps
- · Lightweight, foldable design
- Non-allergenic & latex-free

Applications

- Workplace Protection during grinding, sanding, woodworking, drywalling and masonry
- Home Protection during yardwork and sweeping
- Food Processing
- Mining
- Metal foundry
- Electronics factories
- Pharmaceuticals

Technical Specifications

Function: Anti-dust PM2.5

Certifications: ISO / TUV / NIOSH N95 / L.A /CE

Material: PP Non-woven fabric, High-efficiency low-resistance meltblown, Electrostatic cotton capacity

Usage: PM2.5 Anti Dust Pollution

Color: White

Packaging: 20 Respirators/box, 20 boxes/case

Country of origin: China

Donning Instructions

- Step 1: Open the respirator with both hands.
- Step 2: Cup the respirator firmly against you face with the nosepiece on the bridge of your nose.
- Step 3: Stretch and pull the lower headband over the head and position below your ears. Stretch and pull the top headband on the back of your head above your ears.
- Step 4: Press plastic nosepiece to conform snugly around your nose.











WWW.TECHNIWELDUSA.COM